User Manual

DriveStation

HD-HB160U2/HD-HB250U2

BUFFALO™

Unpacking and Setup

This section provides unpacking and setup information for DriveStation.

Open the shipping carton of DriveStation and carefully unpack its contents. The carton should contain the following items:

Main Unit (DriveStation)	1
Power Adapter	1
DriveStation Feet	2
USB Cable	1
DriveNavigator Installation CD	1
Quick Setup Guide	1

If any items are missing or damaged, please contact the reseller or retailer from which the product was purchased.

The front face of the DriveStation has a protective plastic film covering for protection from scratching during assembly and shipping. The film can be removed by peeling it away from any corner of the front face.

- Flip the power switch on the back of DriveStation to the OFF position. Plug DriveStation's power cord into a power outlet. Then, connect the included USB cable into the USB port on the back of DriveStation.



- Connect the USB cable into the USB port on the computer or device you are adding the DriveStation to.



Windows 2000 & XP

- Flip the power switch on the back of the DriveStation to the ON position.



- In Windows 2000 and XP, the DriveStation will automatically install upon power-on.



- Open ‘My Computer’ and the new drive will be present. By default it will pick the first available drive letter and will be named ‘Local Disk’. The DriveStation comes pre-formatted so you may begin using it immediately.



- The DriveNavigator CD includes several useful utilities for your Windows System. Please insert the DriveNavigator CD into your CD-ROM Drive to learn more about them.

Windows 98SE & ME

- Insert the DriveNavigator CD into your CD-ROM Drive. Shortly thereafter the DriveNavigator Easy Setup program will launch.



NOTE: If the DriveNavigator program does not launch, it can be launched by pressing on the ***'Start Menu'*** and selecting the ***'Run'*** option. Once the dialog opens, type ***X:\easysetup.exe*** (where X is CD-ROM drive letter).

- The Easy Setup Wizard will begin running. Please follow the on screen documentation to complete the DriveStation Setup for your system. The DriveNavigator CD includes several useful utilities for your Windows System. Please explore the CD contents to learn more about them.


Flip the power switch to the off position.
Attach the USB cable to the USB Hard Drive via the included cable.
Turn the unit off by flipping the power switch. Then connect the USB hard disk to the included USB cable.
Back
Exit
Next

Using DriveStation with LinkStation

- Flip the power switch on the back of the DriveStation to the ON position.

- Please refer to the User Manual on the LinkStation's LinkNavigator CD for LinkStation USB Disk configuration.





Troubleshooting

The following is a list of common issues with the DriveStation. Following each common issue are possible resolutions.

I see the DriveStation in 'My Computer' but I cannot access it.

The drive requires formatting. Try using the Disk Formatter Utility on the DriveNavigator CD-ROM. Consult the manual for the Disk Formatter Utility for more help. The manual can also be found on the DriveNavigator CD-ROM.

I cannot see the DriveStation in 'My Computer'.

Verify that the POWER light is lit green. If it is not, then ensure that the power switch is in the ON position.

Try toggling the POWER MODE switch right below the power switch. The POWER MODE switch toggles whether the device is powered up via a USB signal or purely based on the power switch's position.

If you have installed the Power Save Utility, then verify that the DriveStation was not put into power saving mode. Consult the manual for the Power Save Utility for additional help. The manual can be found on the DriveNavigator CD-ROM.

*Verify that the hard drive inside the DriveStation is spinning. This can be verified by placing your hand on the sides of the case and feeling for a slight vibration. Also, after the DriveStation has been powered on for fifteen minutes or more it will begin to get warm. If neither of the preceeding tests verified that the hard drive is spinning, then please call technical support at **866-752-6210** for further assistance.*

If you are experiencing any additional troubles, please contact our live 24x7 technical support for additional assistance. They can be reached toll-free at ***(866) 752-6210***.

USB Standards:	USB Specification Rev. 2.0
Capacity:	160, 250 GB
Seek Time:	Max. 11 milliseconds
Transmission Speed:	Max. 480 Mbps
Power Consumption:	Max. 25W, Average 17W
Power Supply:	AC100V 50/60Hz
Dimensions:	53(W) x 173(H) x 164(D) mm
Weight:	3.15 lb.
Operating Environment:	5 - 35 degree C 20-80% humidity (non-condensing)

Technical Support

Buffalo Technology offers toll-free technical support 24 hours a day, 7 days a week for this product. Customers in the United States and Canada may obtain technical support using the following information:

Web: ***www.buffalotech.com***
E-mail: ***info@buffalotech.com***
Telephone: **866-752-6210 (USA & Canada only)**

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Buffalo Technology (USA) products come with a one-year limited warranty from the date of purchase. Buffalo Technology (USA) warrants to the original purchaser the product; good operating condition for the warranty period. This warranty does not include non-Buffalo Technology (USA) installed components. If the Buffalo product malfunctions during the warranty period, Buffalo Technology (USA) will, at its discretion, repair or replace the product at no charge, provided the product has not been subjected to misuse, abuse, or non-Buffalo Technology (USA) authorized alterations, modifications or repair.

When returning a product, include your original proof of purchase. Return cannot be processed without proof of purchase. Shipment of returned products to Buffalo Technology (USA) is the responsibility of the purchaser. All expressed and implied warranties for the Buffalo Technology (USA) product line are limited in duration to the above period.

Under no circumstances shall Buffalo Technology (USA) be liable in any way to the user for damages, including any lost profits, lost savings or other incidental or consequential damages arising out of the use of, or inability to use the Buffalo products. Buffalo Technology (USA) reserves the right to revise or update its products, software, or documentation without obligation to notify any individual or entity.

Please have your proof of purchase receipt to get warranty support. ***All defective products shall be returned to the original place of purchase with a copy of proof of purchase.*** *All RMAs are governed by the RMA policy or procedures of each individual reseller selling Buffalo WLAN products. In no event shall Buffalo Technology (USA) liability exceed the price paid for the product from direct, indirect, special, incidental, or consequential damages resulting from the use of the product, its accompanying software, or its documentation. Buffalo Technology (USA) does not offer refunds for any product.*

Buffalo Technical Support Information
(Please have your proof of purchase when calling Buffalo Technical Support)

United States of America & Canada

Buffalo Technology (USA) Inc.
4030 West Braker Lane, Suite 120
Austin, Texas 78759-5315

24/7 Help Line: **(866) 752-6210**
email: **help@buffalotech.com**
web: **www.buffalotech.com**

4030 W. Braker Ln. Suite 120
Austin, Texas 78759
Tel: 800-456-9799
Fax: 512-794-8606

Technical Support is available 24 hours a day, 7 days a week

(USA / Canada)

Toll-Free: 866-752-6210

email: info@buffalotech.com

©2004, Buffalo Technology (USA), Inc.